




10. Setting Flow



◆How to Enter Password
It is necessary to enter password to shift to setting mode. Enter [0000] and shift to password setting mode when you set password at the first time.
*When setting password, be careful for handling and note it.



















◆How to Initialize Password
When you forget the password, initialize it in the following procedures. (Initial: [0000])
It is impossible to decode the set password.



11. How to Set the Parameters related to Power Measurement

Set before measuring.
Select setting item with ITEM and press SET and the value will be blinking.

Set with ITEM and SHIFT
When you select [YES] with the confirmation window and press SET, the setting values are decided.



•Refer to User's manual for the other settings.